




EN - To unfold

ES-Para desplegar / FR-Déplier / DE-Zum Ausklappen / IT-Aprire / PT-Para desdobrar / CA-Per desplegar / NL-Uitklappen / PO-ROZŁOŻENIE / RO-Extindere / BG-За разгъване / HU-Kinyitni
EL-Για να ανοίξετε / TR-Açmak için / ع- للفتح / TH- unfolding / RU-Разложить / SV-Fäll upp / DA-Udklapning / NO-Brette ut / CS-Rozložit / SR-Da se rasklopi / HR-Rasklopiti / JA-広げる。
ZH- 展开 / LT-Išskleisti / SK-Pre rozloženie / 展开 - HE


1



2



3



4




EN - To fold

ES-Para plegar / FR-Plier / DE-Zum Einklappen / IT-Piegare / PT-Para dobrar / CA-Per plegar / NL-Inklappen / PO-ZŁOŻENIE / RO-Pliere / BG-За сгъване / HU-Összecsuni / EL-Για να κλείσετε / TR-Katlamak için / ع- للفتح / TH- folding / RU-Сложить / SV-Fäll ihop / DA-Sammenklapning / NO-Brette sammen / CS-Složit / SR-Da se sklopi / HR-Sklopiti / JA-折りたたむ。/ ZH- 折叠 / LT-Suskleisti / SK-Pre zloženie / 折叠 - HE


1



2



3



4

